



FORD 2004-14 F-150 Rear Air Spring Kit

Thank you for choosing Rough Country for all your vehicle needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product.

Check all fasteners for proper torque. Check to ensure for adequate clearance between all components.

Periodically check all hardware for tightness.

▲ NOTICE Airbags will not increase the maximum load capacity.

Kit Contents:

- Air Bags x2
- Dr Side Upper Bracket x1
- Pass Side Upper Bracket x1
- Dr Side Lower Bracket x1
- Pass Side Lower Bracket x1
- 90° Fittings x2
- Inflation Valves x2
- U-Bolt Plates x4

Tools Needed:

- 10mm Socket/Wrench
- Drill
- 1" Hole Saw Drill Bit

Hardware Included:

- 3/8" x 1" Bolts x8
- 3/8" x 1-1/2" Bolts x6
- 3/8" Flat Washers x14
- 3/8" Lock Washers x14
- Small Flag Nuts x4 (2004-08 Models)
- Large Flag Nuts x4 (2009-14 Models)
- 3/8" Body Clips x2
- 1263Bag2 (U-Bolts) x1
- Air Line x20ft
- Cable Ties x6





Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs





INSTALLATION INSTRUCTIONS


1. Jack up the rear of the vehicle and place on jack stands. Remove the rear wheels.
2. Remove the rear bump stops using a 10mm socket and remove anti-wrap U-bolts if equipped. **See Photo 1.**
3. Install the supplied 3/8" clip in the stock bump stop hole. **See Photo 2.**





4. Install the upper air bag bracket using the supplied 3/8" bolt in the new clip for **2004-08 models** or the stock bolt for **2009-14 models**. **See Photo 3 and Photo 4.**





5. **For 2004-08 Model Vehicles Only:** Measure out 3/4" from the side edges of the upper bracket and mark using a paint pen. **See Photo 5.**
6. **For 2004-08 Model Vehicles Only:** Drill a 1" hole on the marked points. **See Photo 6.**



7. Install the supplied flag nuts and 3/8 bolts using a 9/16" socket/wrench. **See Photo 7.**
8. Install the lower bracket to the air bag with 3/8" bolts using a 9/16" socket/wrench. **See Photo 8.**



9. Install the air bag assembly with the tall side of the bracket towards the front and secure to the upper bracket using 3/8" bolts and 9/16" socket/wrench. **See Photo 9.**
10. Reinstall anti-wrap U-bolts, if equipped or install supplied U-bolts and U-bolt plates using a 5/8" socket/wrench. **See Photo 10.**



11. Install the airline.
12. Put on wheels and lower.



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

